

---

# ZTE MF627 Software Upgrade Guide for MAC OS 10.5 and up version

By: SBW Resolution Team

## Steps:

The Download tool can run only through Windows®XP or Windows®Vista. The purpose of the tool is to update the software of the MF627 modem

1. Start the computer.
2. Install **SalesDL\_MF627V1.xx.xxsetup.exe**. After finishing the installation run **SalesDL\_MF627V1.xx.xx.exe** on the desktop.
3. Insert the MODEM into the USB port of the computer. Then it will be mapped to a CD-

ROM under “My Computer”, right click on the driver to eject the CD-ROM.

The port and the software version will show automatically


#### 4 . Press select software version

The screenshot shows a software update tool window titled "SalesDL\_MF636V1.01.07". The window contains several fields and buttons:

- COM1 dropdown menu
- No Phone text field
- Empty text field
- READY status indicator
- Warning section with red text: "Remove the SIM card from the stick then insert the stick.", "Do not close or exit the update tool while the firmware flashing is running.", and "Do not insert or remove any USB devices until the update is complete."
- Download button
- Software Version dropdown menu (highlighted with a red circle)
- Empty text field
- 0/100 progress indicator
- Clear Record button
- Status table:

All Counts:	2/2	Last clear time:	0/0/0 00:00
Now Counts:	2/2	Current time:	11/19/2010 10:59

5. Locate the software version then press OK



6. Press button to start download operation, The **PASS** sign will show after successful download operation

**Warning: Never close the tool when download procedure is running, such operations maybe seriously damage the card permanently!**

6. Press button to start download operation,



7. The **PASS** sign will show after successful download operation

**Warning: Never close the tool when download procedure is running, such operations maybe seriously damage the card permanently!**



---

Thank You

